# The autonomous powder fire extinguishing device





## About FINFIRE



The autonomous powder fire extinguishing devices "SPHERE", "TAB" and "KUPOL" are used as a primary means of extinguishing fires.

The devices are triggered automatically by fire, they are completely autonomous, their use does not require human presence, and for installation - no special sensors or complex installation.

The simple design of the device does not require special skills or great physical effort when using it, and there is no need to approach the source of the fire, which allows FINFIRE to be used by untrained people.


By equipping your premises with FINFIRE, you reduce the risk of fire spreading several times.

Watch FINFIRE video



## Fire classes

#### FINFIRE are used to extinguish fire classes



#### FINFIRE

#### +7-919-529-86-85


## Application areas



Buildings, apartments



Agricultural buildings, cottages



Public places



Stores



Gas and oil refining stations



Railway transport





Control Dispatch points



Cable shafts, electric stations



......... Sea and river



Automobile

transport

transport



Oil and gas production



Storage and production facilities



Electric transport





Aviation and armored vehicles

Radio and television





## Are made from



FINFIRE "SPHERE", "TAB" and "KUPOL" consist of a polystyrene (foam) case with fire extinguishing powder inside.

The fuse cords run along the surface of the case, which are connected to a spray cartridge.

- The devices are triggered by contact with an open flame.
- False alarms are excluded.
- The devices are safe for humans and animals.
- Do not contain harmful substances.



## Operating principle of the device



1. Ignition.



**3**. The fuses along the casing activate the powder sprayer inside.



**2**. Fire comes in contact with the FINFIRE fire extinguisher.



**4**. After the activation, the casing is destroyed, and extinguishing powder is sprayed onto the fire.



## Advantages



They are triggered automatically by fire without human intervention



Instantly extinguishes fire (in 3-10 sec.)



Protects volume up to 5 m<sup>3</sup>



Easy to use – does not require special skills



Maintenance free



Notifies when triggered by a clap (118 dB)



Safe for humans, animals and the environment



Long service life - 5 years





## Device certificate



Certified by The Federal State Budgetary Institution "The Research Institute of Fire Protection of All-Russian Order "Badge of Honor" of the EMERCOM of Russia".



## Certified fire extinguishing powder



Certificate of Conformity

No. EAEC RU C- RU.ПБ97.И.00394/22

International certificate, Germany

Fire extinguishing powder FINFIRE ABCE is a balanced composition of fire extinguishing and auxiliary components.
1. Extinguishing components:
Lower the temperature at the source of ignition.

- Release fire-retardant inert substances.
- Chemically inhibit the combustion process.
- Isolate the source of fire from oxygen supply.
- Act as fire arresters by cutting the flame.

2. Additives help to reduce absorption and caking of fire extinguishing powder, increasing its service life and boosting its extinguishing properties.

### FINFIRE

## No analogues



FINFIRE "TAB" and "KUPOL" have no analogues.

They are our own development of our plant's specialists.

A special feature of the devices is their unique mounting method this is a specialized heat-resistant tape located on the back side, with the help of which the devices can be attached to any flat surface.

The compact design allows you to install them in the most hard-toreach places.









#### Patent



FINFIRE devices are patented: Patent for utility model No. 184841.



Our partners





## Technical characteristics

Параметры	FINFIRE "SPHERE"	FINFIRE "TAB"	FINFIRE "KUPOL"
Quick action time	up to 10 sec.	up to 10 sec.	up to 10 sec.
Protected volume	up to 5 m <sup>3</sup>	up to 5 m <sup>3</sup>	up to 5 m <sup>3</sup>
Dimensions (LxWxH)	150x150x150 mm ± 2%	150x150x50 mm ± 2%	150x150x80 mm ± 2%
Weight of the device	1400 g ± 10 g	560 g ± 7 g	660 g ± 7 g
Extinguishing powder weight	1340 g ± 10 g	500 g ± 7 g	600 g ± 7 g
Working temperature range*	from -50°C to +60°C	from -50°C to +60°C	from -50°C to +60°C
Activation sound	no more than 118 dB	no more than 118 dB	no more than 118 dB
Operating mode	autonomous	autonomous	autonomous
Ecology	friendly	friendly	friendly
Service life	5 years	5 years	5 years

\*In places where FINFIRE is stored and installed, air humidity should not exceed 80%

## FINFIRE

## Equipment of devices



**FINFIRE "SPHERE"** is supplied in individual packaging with a universal mount.

Equipment:

- The autonomous fire extinguishing device FINFIRE "SPHERE" 1 pc.

- Bracket (multipurpose fastener) 1 pc.
- Datasheet/manual 1 pc.
- Set of hardware for mounting the device 1 pc.
- Packing (box) 1 pc.

**FINFIRE "TAB"** is supplied in individual packaging with fastening using specialized double-sided tape.

FINFIRE

Equipment:

АВТОНОМНОЕ УСТРОЙСТВО ПОЖАРОТУШЕНИ

FINFIRE

- The autonomous fire extinguishing device FINFIRE "TAB" 1 pc.
- Double-sided adhesive tape / 1 pcs
- Datasheet/manual 1 pc.
- Packing (box) 1 pc.

**FINFIRE "KUPOL"** is supplied in individual packaging with fastening using specialized double-sided tape.


Equipment:

- The autonomous fire extinguishing device FINFIRE "KUPOL" 1 pc.
- Double-sided adhesive tape / 1 pcs
- Datasheet/manual 1 pc.
- Packing (box) 1 pc.



## Package dimensions

FINFIRE "SPHERA"





## FINFIRE "SPHERE". Instructions for use

Automatic mode:



To install the device, place the fastener so as the larger circle diameter faces up.






1. Place the device at a distance of up to 30 cm from the top or side above the place of high risk of fire. 2. Secure the device with a universal mount. Make sure that the arrow on the device is pointing down.



3. Upon contact with fire, the device automatically activates with a warning pop and sprays fire extinguishing powder onto the source of the fire.



## FINFIRE "SPHERE" Installation



## FINFIRE "TAB". Instructions for use

Automatic mode:



From the back of the device, it is necessary to peel off the protective film of double-sided tape and attach it to the object of protection with it.



1. Place the device at a distance of up to 30 cm from the top or side above the place of high risk of fire.






2. Secure the device with a double-sided adhesive tape on a flat and dry surface.

3. Upon contact with fire, the device automatically activates with a warning pop and sprays fire extinguishing powder onto the source of the fire.



## FINFIRE "TAB" Installation





## FINFIRE "KUPOL". Instructions for use

Automatic mode:



From the back of the device, it is necessary to peel off the protective film of double-sided tape and attach it to the object of protection with it.



1. Place the device at a distance of up to 30 cm from the top or side above the place of high risk of fire.



2. Secure the device with a double-sided adhesive tape on a flat and dry surface.






3. Upon contact with fire, the device automatically activates with a warning pop and sprays fire extinguishing powder onto the source of the fire.



## FINFIRE "KUPOL" Installation





# FINFIRE +7-919-529-86-85

info@finfire.ru

www.finfire.ru



